



Motion Studio 2.16.07

May 12th, 2023

Release Notes (changes from version 2.16.06)

Item	Comments
MS	
Ethernet cameras	Optimal Jumbo data size (see "What's New" document).
All cameras	Advanced color chart calibration (see "What's New" document).
All cameras	Options import and export (see "What's New" document).
All cameras	Added time stamp option to open dialog (see "What's New" document).
Images	Improved Go to dialog (see "What's New" document).
Auto-Iris	Added min and max auto-iris limits (see "What's New" document).
CCM cameras	Configurable 8 bit addressing (see "What's New" document).
Short exposure	Improved exposure precision on cameras with short exposure option.
Playback	Show elapsed time in playback bar tooltip.
Distance calculation	Fixed distance calculation when live and playback resolution is not set to "Full".
Multi-raw file view	Allow adding new file to current list.
Raw Files	When a parameter changes and raw file is closed, ask to save file (fixed).
Raw Files	If original pixel depth is above 8/24 bit, the user can edit pixel depth when a raw file is played back.
YUV422	Added support to read YUV422 files (non IDT raw).
Clips	Fixed support to Motion Monitor clip files.
Write to Disk	When W2D is enabled, disable record mode configuration and set it to circular.
Admin setup	Fixed management of Administrator setup.
Version	Print software version dynamically on splash screen image.
DB Viewer	Reworked DB viewer. Removed display of DAS files and tracking.
Open camera/raw	Fixed sort of cameras and raw files in open dialog. Fixed sort by name and camera model.
8 bit bitmaps	Fixed crash when 8 bit bitmap is displayed in Motion Studio.